

SILAMPOS

SINCE
1951

EMOTION





Batterie 9 pcs + 24 couverts

Dim.(cm)	Hauteur(cm)	Cap.(L)	Article
---	---	---	637123WA0496



Casserole

Diam.(cm)	Hauteur(cm)	Cap.(L)	Article
Ø16	8.1	1.6	637123WA1116



Couvercle en verre

Diam.(cm)	Hauteur(cm)	Cap.(L)	Article
Ø14	---	---	632000WA8114
Ø16	---	---	632000WA8116
Ø20	---	---	632000WA8120
Ø24	---	---	632000WA8124
Ø26	---	---	632000WA8126
Ø28	---	---	632000WA8128



Faitout

Diam.(cm)	Hauteur(cm)	Cap.(L)	Article
Ø16	8.1	1.6	637123WA1016
Ø20	9	2.7	637123WA1020
Ø24	10.1	4.4	637123WA1024
Ø26	10.6	5.5	637123WA1026
Ø28	11	6.6	637123WA1028



Grill carré anti-adherent

Diam.(cm)	Hauteur(cm)	Cap.(L)	Article
Ø27	3.9	---	63222AWA6127



Marmite

Diam.(cm)	Hauteur(cm)	Cap.(L)	Article
Ø16	11.1	2.2	637123WA6616
Ø20	13.1	4	637123WA6620
Ø24	15.1	6.7	637123WA6624
Ø26	16.1	8.4	637123WA6626
Ø28	17	10.3	637123WA6628



Poêle conique anti-adhérente

Diam.(cm)	Hauteur(cm)	Cap.(L)	Article
Ø20	4.4	1	63C12AWA5620
Ø24	4.9	1.7	63C12AWA5624
Ø28	5	2.3	63C12AWA5628



Poêle/friteuse+protecteur

Diam.(cm)	Hauteur(cm)	Cap.(L)	Article
Ø24	6.5	2.6	632122WA9624

Pot au lait

Diam.(cm)	Hauteur(cm)	Cap.(L)	Article
Ø14	12.4	1.9	637123WA2214